

# SOS Personal Alarm and GPS Tracker Commands

To set up the 3 emergency contacts, text:

A1,phone number

B1,phone number

C1,phone number

Example: A1,0777777777 .

Tracker will reply: SET MOBILE NUMBER 1/2/3 OK.

To set a geofence when device leaves an area, text:

G1,1,0,300M (for 300 metres, but distance can be adjusted to whatever suits you).

Example: G1,1,0,004KM

Tracker will reply: SET GEOFENCE 1 OK.

Repeat same step for geofence two (G2) and geofence 3 (G3).

To turn off a geofence, text:

G1,0 or G2,0 or G3,0

To change the time zone, text:

TZ+01 or T-01 to add or take 1 hour to UTC time zone.

Tracker will reply: SET TIME ZONE OK

To set up the user name, text:

Name1,(user name) to define user name.

Tracker will reply: ADD NAME OK.

Name0 to delete user name.

Tracker will reply: DELETE NAME OK.

To receive a written address instead of a link, text:

Add

Will work with GPRS only.

Tracker will reply with address.

To set up low battery alerts, text:

**Low1** to turn on low battery alarm.  
Tracker will reply: LOW BATTERY ALARM ON.

**Low0** to turn off low battery alarm.  
Tracker will reply: LOW BATTERY ALARM OFF.

To set up LED lights, text:

**LED1** to turn off lights.  
Tracker will reply: LED LIGHTS OFF.

**LED0** to turn lights back on.  
Tracker will reply: LED LIGHTS ON.

To set up fall detection, text:

**FL1** to activate fall detection.  
Tracker will reply: FALL DETECTION ON.

**FLO** to deactivate fall detection.  
Tracker will reply: FALL DETECTION OFF.

To set up text alerts, text:

**SMS0** to turn off text alerts.  
Tracker will reply: SMS ALERT CANCELLED.

**SMS1** to activate text alerts.  
Tracker will reply: SMS ALERT ENABLED.

To reboot the device, text: **Reboot**

To view the current settings of the device, text: **Status**

To reset the device to factory settings, text: **RESET!** (this will delete all existing settings such as emergency contacts and geofences)

To find out the device's IMEI number text:

## LED STATUS

### Green light:

Single flash every 3 seconds	Connected to mobile network.
Double flash every 3 seconds	Connected to GPRS Network. Mobile Data.
Slow flash every 3 seconds	Connecting to GSM mobile network.
Solid light	No sim detected

### Blue light:

Single flash every 3 seconds	GPS signal found
Slow flash every 3 seconds (1 second on 3 seconds off)	No GPS signal found
No light (when not charging)	GPS in sleeping

### Blue light whilst charging

On solid	Charging
Blinking quickly	Battery under 15%
Off or blinking slowly	Fully charged or not charging