



4 Easy Steps to adjust for day light saving time

Every year the clocks will go forward one hour on the last Sunday in March and back on the Last Sunday in October.

For our dual display and our Unforgettable 2-in-1 day clock, it's very easy to change the time to keep up to date with day light saving time.

1. Simple press the Menu Button on the back of the clock



2. The Set Time option should be selected upon the menu opening, however please use the UP / DOWN buttons to move between rows if it is not.

CURRENT TIME	Set Time	07:10AM	
	Set Date	17-12-2016	TODAY'S DATE
12 or 24 HOUR CLOCK	Time Mode	24 Hours	
	Date Mode	Day- Month-Year	DD-MM-YYYY or MM-DD-YYYY
8 LANGUAGES	Language	< English >	
WHEN SCREEN GOES BRIGHTER	Morning Time Set	07	WHEN CLOCK CHANGES FROM MORNING TO AFTERNOON, EVENING & NIGHT (Time of day display only)
	Afternoon Time Set	12	
	Evening Time Set	17	
WHEN SCREEN GOES DIMMER	Night Time Set	22	

3. Press the RIGHT button until the hour is selected and then simple press the UP button to add one hour or the Down button to remove one hour.
4. Press OK to confirm and then MENU to exit.